




Lenovo Yoga 3 Pro SSD Replacement

This guide will show you how to access and replace the SSD.

Written By: Federico LopezCasildo Jr



INTRODUCTION


Accessing and replacing the Solid State Drive (SSD) is useful if it has been damaged or if you wish to swap it out with another one for extra storage space. Exercise extreme caution while removing and handling the drive. Although the drive is fairly sturdy, even a small dent can permanently damage it.




TOOLS:

- [T5 Torx Screwdriver](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery




 Before opening your laptop, make sure it is powered off.

- Remove the ten 3.3 mm screws from the base cover using the T5 Torx screwdriver.

Step 2



- Slide the plastic opening tool between the base cover and the frame to pry open the computer.
- Slowly go around the entire perimeter of the computer until all edges are loose.


 Make sure the plastic opening tool doesn't go too far into the device.

Step 3



- Remove the panel and place it in a safe location.

Step 4



- Remove the six 3.5 mm screws surrounding the battery using the Phillips 00 screwdriver.


Step 5



- Remove the battery.



i It is helpful to lift and hold the battery as shown and wiggle it out from the connector.

Step 6 — SSD



- Remove the 1.5 mm screw using the Philips 00 screwdriver.

Step 7



- Use the plastic opening tool to remove the hard drive/SSD.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 04:30:11 PM.